




TUDOR

GMT
WATCHES

SETTINGS




SCREWED-DOWN POSITION [position A]

Your TUDOR watch is equipped with a screw-down crown. Once this is fully screwed down against the case, your watch is guaranteed waterproof.

MANUAL WINDING [position B]

A watch equipped with a self-winding mechanical movement is wound automatically by wrist movements alone. To ensure optimum winding, wear your watch daily.

Before you first use the watch or if it has stopped, you will need to wind it manually by unscrewing the crown and then turning it clockwise; the other direction is inactive.



REFERENCE TIME
Geneva: 10:10 a.m.

SETTING THE REFERENCE TIME [position D]

To set the reference time, unscrew the crown and then pull it out to the second notch. The seconds hand is stopped, allowing you to set the time to the precise second.

Put the bezel in the neutral position (align the triangle on the bezel with the 12 o'clock marker on the dial).

Set the reference time using the 24-hour hand (against the graduations on the bezel) and the minute hand (against the graduations on the dial) by turning the crown in either direction.

Setting the reference time also moves the conventional hour hand (local time). For this reason, the reference time must be set before setting the local time.



REFERENCE TIME
Geneva: 10:10 a.m.

LOCAL TIME
New York: 4:10 a.m.

SETTING THE DATE AND THE LOCAL TIME [position C]

To set the date and the local time, pull the crown out to the first notch.

Set the date by turning the crown in either direction. The hour hand moves in increments of one hour. The date changes when the hour hand passes midnight, in either direction, after two complete turns around the dial.

Set the local time by turning the crown in either direction. The hour hand moves in increments of one hour. Be aware of the difference between noon and midnight (the date changes as the hour hand passes midnight).

Push in and then screw down the crown.

The local time is identical to the reference time (24-hour hand) if the wearer is currently located in his reference zone. It can be easily adjusted when travelling.


ADJUSTING THE LOCAL TIME [position C]

When travelling, to adjust local time only (without affecting the 24-hour reference time display), unscrew the crown and then pull it out to the first notch.

Set the local time by turning the crown in either direction. The hour hand moves in increments of one hour. The date is linked to local time and changes automatically when the hour hand passes midnight.

Push in and then screw down the crown.

The 24-hour hand indicates the time in the reference time zone and allows the wearer to distinguish daytime hours from nighttime hours.



REFERENCE TIME
Geneva: 10:10 a.m.

LOCAL TIME
New York: 4:10 a.m.

**TIME IN THE THIRD
TIME ZONE**
Tokyo: 6:10 p.m.


THIRD TIME ZONE DISPLAY [setting via the bezel only]

A third time zone can be displayed by using the rotatable bezel and the 24-hour hand. It is based on the reference time.

To display the third time zone, turn the bezel clockwise (for a negative time difference) or anticlockwise (for a positive time difference) according to the time difference between the reference time (24-hour hand) and the time in the desired time zone.

The 24-hour hand read against the bezel indicates the time in the third time zone. The minutes are shown on the dial by the minute hand.

To return to the reference time display, turn the bezel in either direction to place the triangle on the bezel opposite the 12 o'clock marker on the dial.



VISIT TUDORWATCH.COM

AND EXPLORE MORE

RECOMMENDATIONS

Bronze: Your Black Bay Bronze is designed in bronze, in this case a high-performance aluminium bronze alloy, which guarantees the development of a subtle and unique patina to match its user's habits.

Cleaning: Use a microfibre cloth and wash the metal, rubber, fabric bracelets and waterproof cases from time to time with a soft brush and soapy water. We recommend that you do not use abrasive or corrosive products (solvents, detergents, perfume, etc.).

Guarantee: Refer to the guarantee manual supplied with your watch.

Leather: To preserve your leather strap, we recommend protecting it from water and moisture.

PVD: Your Black Bay Dark is finished with a black coating obtained using a Physical Vapour Deposition (PVD) process. Although the coating is extremely resistant, regular wear and tear can cause this decorative layer to deteriorate over time. The warranty does not cover this type of aesthetic wear.

Salt water: Always rinse your watch with fresh water.

Screw-down winding crown: After each operation, remember to push the crown back in and screw it back down carefully against the case, in order to preserve your watch's waterproofness.

Service: Each TUDOR watch is a complex precision mechanism and, as such, requires periodic servicing and maintenance to guarantee optimum performance. Expert TUDOR servicing can be carried out via any of the Official Retailers and Service Centres in the extensive ROLEX or TUDOR service network. Visit TUDORWATCH.COM to view the list of Official TUDOR Retailers and Service Centres in your area.

Strap: Only Official TUDOR Retailers are authorized to change the watch strap.

REFERENCE

MODEL

CALIBRE

POWER RESERVE

WATERPROOFNESS

79830RB

BLACK BAY GMT

MT5652

70 h

200 m



TUDOR

© Montres TUDOR SA
Rue François-Dussaud 3-5-7
1211 Geneva 26, Switzerland

TUDORWATCH.COM

Montres TUDOR SA reserves the right to modify the models illustrated in this publication at any time.

587.72 EN – 12.2017

